

EN

## CLEANING INSTRUCTION!

Please comply accurately with the following instructions and don't pull off the protective foil suddenly!

ad notam's Magic Mirror V2 coated glass utilizes optical coatings to enhance performance. Improper cleaning could negatively affect the coating's optical properties, and will void the product's warranty. Please follow the guidelines outlined below when cleaning Magic Mirror V2 coated glass products.

To avoid damages please ensure the observance of the following instructions:

- Use mild, fast-drying household spray glass cleaning solutions with ammonia and water. Ammonia concentration not to exceed 1.5% of weight.
- Use a lint-free paper cloth that is non abrasive or a soft cotton cloth without seams, buttons, plastic or metal parts.
- Pre-moisten glass surface with water or cleaning solution to loosen dried dirt and debris before attempting to wipe it away - **never** scrape with a metal blade or tool
- **Never** use abrasive household detergents as cleaning agents.
- **Never** attempt to remove debris / dirt from the glass by using a scraper or razor blade.
- **Never** allow water or cleaning solution residue to dry on the glass. Long-term exposure to acidic or basic cleaners may cause damage to the coated surface.
- **Never** trap abrasive particles between the cloth and the glass surface while wiping away the cleaning solution.

This product, parts, components and the assembly are protected by or might be part of one of the following intellectual property rights: US 7455412 B2, US 7589893 B2, EP 1168285 B2, EP 1429308 B2

MAGIC  
MIRROR®

Registered trademark of the ad notam group.